

PRODUCT INFORMATION



Algae Cleaner

Art no: 1111

Removal of algae, moss, lichen



Algae Cleaner is used for removal and cleaning of algae, moss, lichen, mould and other growths **Algae Cleaner** is bio-degradable **Algae Cleaner** can be used in both cold and warm **Algae Cleaner** is an efficient disinfective against gram negative and gram positive bacteria.

Instructions of use

Algae Cleaner is used for removal of algae, moss, lichen, mould and other growths from most surfaces.

Algae Cleaner can also be used in a bath to clean tools and instruments.

Algae Cleaner is also used as a protection to prevent growth on surfaces and circulation systems.

Surfaces:

Dirt, grease and other pollutions must first be cleaned. Apply **Algae Cleaner** with a low-pressure spray gun. Let the product work on the surface for 5-30 min. Jet off with high-pressure water.

Tools:

Immerse tools to be cleaned in a bath, let be for approx. 15-30 min. Rinse with water.

Control of algae:

Apply **Algae Cleaner** with a low-pressure spray gun. Leave the product. Do not rinse off. **DO NOT** mix with anionic surfactants as dish-washing detergents.

Dosage

Disinfection of instrument, dilute 1:10 with water.

Disinfection of surfaces, dilute 1:10 with water.

Disinfection of bathrooms, dilute 1:10 with water.

Cleaning up in kitchens, dilute 1:25 with water.

Preventive protection on surfaces, dilute 1:25 –50 with water.

Control of algae in circulation systems, dilute 1:100 with water

Technical data

- Transparent liquid.
- Supplied in 1 litre plastic bottle, 5, 10 and 25 litres plastic container.
- Specific weight 1,0 kg/litre
- pH value 10,5
- Contains Benzalkonium chloride.

Storage

Store frost free in original container.

Storage Time

24 months in unopened container.

Safety precautions

Use protective clothing, gloves and glasses.

Marking



Irritating to eyes and skin

BPS 7111 is not classified as dangerous goods.

Modified: 2009-02-18

This product information is intended as a guide for use of this product. TRION TENSID AB cannot give any guarantee for end result achieved. Applicator of product shall carry out testing and be responsible for the result.

TRION TENSID AB

Svederusgatan 1-3 | SE-754 50 UPPSALA | SWEDEN Tel: +46 18-15 61 90 Fax: +46 18-69 66 27

Email: info@trion.se Homepage: www.trion.se